Troubleshooting		
Digilock KP-н and WP-н		
Problem	Possible Reason	Solution
There is no audible sound when touching the keypad and the lock is unlocked	 Low Batteries Lock is not properly installed 	 ❖ Replace the batteries, see "Instructions for Changing the Batteries" ❖ Uninstall the lock and assemble in your hands. If the lock is functioning it is not defective. Reinstall the lock on your door. If the lock continues to have problems (it may not be adjusted for your door thickness) or if the lock does not function while uninstalled contact Digilock customer service for troubleshooting.
There is no audible sound when touching the keypad and the lock is locked	 Lock is in "sleep state" Low Batteries 	 ❖ Wait one full minute and try the user code again, or unlock the lock with a valid management bypass key ❖ Use a power jumper to unlock the lock. (See "Instructions for using a Power Jumper") and once unlocked, replace the batteries using "Instructions for Changing the Batteries"
The lock locks and unlocks normally, but emits an additional three red blinks and three audible beeps	Low Batteries	Replace the batteries, see "Instructions for Changing the Batteries"

When entering a valid operating code/key the LED emits three red blinks and three audible beeps and the lock does not unlock	❖ Low Batteries	❖ Use a power jumper to unlock the lock. (See "Instructions for using a Power Jumper") and once unlocked, replace the batteries using "Instructions for Changing the Batteries"
The lock continues to go into "sleep state"	 Invalid operating code This user code is not programmed to the lock 	 Use a valid management bypass key to unlock the lock Program the user code to the lock, refer to your programming instructions for
When entering a valid operating code/key the LED emits ten red blinks and ten audible beeps and the lock does not unlock	❖ The lock is binding	 assistance Press firmly in on the lock while entering a valid operating code/key. If this problem persists, the strike plate may need to be adjusted.
The lock is locked; the management key does not allow access and power jumper does not unlock the lock. There is no audible sound when touching the keypad	The lock has failed to recognize valid operating code/keys	Reset the lock see "Instructions for Resetting the Lock"