Product Guide Key Managed **Bolt Mechanism**







CUE is a keypad lock designed to operate for shared or assigned use applications. In shared use functionality, the user chooses any available locker and enters a self-selected 4-digit code to lock and the same code to later unlock. Once unlocked, the locker is available for a different user. In assigned use functionality, the user is assigned a specific locker and a 4-digit code or User Key to operate the lock. A Programming Key unique to the lock system programs up to 25 Manager Keys to the locks for management access, external power, and inspection.

Lock Parts


Front Unit



Rear Unit



Keys



Key Insertion



Initial Setup

New locks operate only by pressing C . Locks must be setup to allow full operation.

- Touch the Programming Key to the key slot until a two-tone beep is heard and the LED turns on. a.
- b. Touch each Manager Key to the key slot. A two-tone beep will be heard for each Manager Key that is successfully registered.
- Touch the Programming Key to the key slot until a two-tone beep is heard and the LED turns off. C.
- d. Repeat above steps for each lock or follow Express Register Manager Key(s) instructions to setup all locks.

Express Register Manager Key(s)

The Programming Key can quickly register the same Manager Key(s) to operate multiple locks.

- Go to the lock registered with the Manager Key(s). a.
- b. Press Com 6 6 0m. The LED will turn on.
- Touch the Programming Key to the key slot until a two-tone beep is heard and the LED turns off. C.
- d. At each lock to be registered, touch the Programming Key to the key slot until a two-tone beep is heard and the LED flashes once to indicate successful registration.
- End express registration,* go to any registered lock and press of then touch the Programming Key to the key slot to operate the lock. e.

^{*} The Programming Key will continue to function in express registration mode until it is used to operate a lock.





Programming Instructions

Register/Add Manager Key(s)

Manager Key(s) can be registered to a lock after Initial Setup has been completed.

- Go to the lock requiring Manager Key(s).
- b. Press Com 5 5 om. The LED will turn on.
- C. Touch the Programming Key to the key slot until a two-tone beep is heard.
- Touch each Manager Key to the key slot. A two-tone beep will be heard for each Manager Key that is successfully registered.
- Touch the Programming Key to the key slot until a two-tone beep is heard and the LED turns off. e.
- Repeat above steps for each lock or follow Express Register Manager Key(s) instructions to register the same Manager Key(s) to multiple locks.

For Lost or Stolen Keys

For a lost or stolen Programming Key:

A replacement Programming Key must be purchased and registered to the lock(s) to prevent the lost/stolen Programming Key from accessing/programming a lock.

For lost or stolen Manager Key(s):

All registered Manager Keys must be erased and only the remaining Manager Keys must be registered to the lock(s) to prevent the lost/ stolen Manager Key from accessing a lock. Purchase additional Manager Key(s) from an authorized distributor.

- Collect all remaining Manager Key(s).
- b. Press Com 5 5 cm. The LED will turn on.
- C. Touch the Programming Key to the key slot until a two-tone beep is heard.
- d. Touch the Programming Key to the key slot again until three sets of two-tone beeps are heard and the LED turns off. All previously registered Manager Key(s) are erased from the lock.
- Follow Register/Add Manager Key(s) instructions to register the remaining Manager Key(s).

Set Lock Functionality

Each lock can be set for either shared or assigned use functionality. The default functionality is shared use. Press © to check functionality. If in shared use, LED is red. If in assigned use, LED is green.

Set lock for assigned use functionality:

- Press Com 65 om. The LED will turn on.
- b. Touch the Programming Key to the key slot until a two tone beep is heard and the LED turns off.
- Follow Assign User Credential instructions to assign a User Code or User Key to operate the lock.

Set lock for shared use functionality:

- а Press Com 5 6 cm. The LED will turn on.
- Touch the Programming Key to the key slot until a two tone beep is heard and the LED flashes once.

Auto Unlock (for shared use functionality only)

When in shared use functionality, each lock can be programmed to auto unlock after a set number of hours. The default setting is OFF (does not auto unlock).

To turn on Auto Unlock:

- a. Press Com 95 cm then touch the Programming Key to the key slot until the LED turns on.
- Set the number of hours: Press 1 99 cm. Two sets of two-tone beeps will be heard and the LED will turn off. For example: Press 4 om to set the lock to auto unlock after 4 hours.

To turn off Auto Unlock:

- Press Com 94 om. The LED will start to flash.
- Touch the Programming Key to the key slot until a two tone beep is heard and the LED turns off. b.







LED Usage Indicator (for shared use functionality only)

When in shared use functionality, each lock can be programmed to have the LED flash or not flash while the lock is in use. The default setting is ON (red LED flashes while lock is in use).

To turn off the LED Usage Indicator:

- a. Press Com 92 om. The LED will start to flash.
- b. Touch the Programming Key to the key slot until a two-tone beep is heard and the LED turns off.

To turn on the LED Usage Indicator:

- a. Press Com 9 1 om. The LED will start to flash.
- Touch the Programming Key to the key slot until a two-tone beep is heard and the LED turns off.

Assign User Credential (for assigned use functionality only)

Make sure that the lock is set for assigned use functionality. Once a user credential is assigned, the previously assigned user credential will no longer operate the lock.

Assign a User Code (default user code = 1234):

- a. Press com then touch a registered Manager Key to the key slot until the LED turns on.
- b. Press C [new 4-digit code] . A two-tone beep will be heard.
- c. To confirm, press [C] [the same 4-digit code] [Cm]. Two sets of two-tone beeps will be heard and the LED will turn off.

Assign a User Key:

- a. Press com then touch a registered Manager Key to the key slot until the LED turns on.
- b. Touch a User Key to the key slot until a two-tone beep is heard and the LED turns off.

Operating Instructions

Operate with a User Code

For assigned use functionality:

- To unlock: Press © [assigned 4-digit code] ©=*.
- To relock: Press Comom.

For shared use functionality:

- To unlock: Press C [the same 4-digit code] To unlock: Press C [the same 4-digit code]

Operate with a User Key

For assigned use functionality:

- To unlock: Touch the assigned User Key to the key slot.
- To relock: Touch the assigned User Key to the key slot.

For shared use functionality:

- To lock: Touch any User Key to the key slot.
- To unlock: Touch the same User Key to the key slot.

Operate with a Registered Manager Key

■ To unlock and lock: Touch a registered Manager Key.**

Operate with a Registered Programming Key

- To unlock and lock: Press Com then touch the Programming Key to the key slot.**
- * The lock will go into "Sleep Mode" (keypad is disabled) after 3 consecutive incorrect user code entries.
- ** If a registered Manager Key or the Programming Key is used to unlock and then relock, the previous user credential will continue to operate the lock.





Support

Sleep Mode

After three consecutive incorrect User Code entries to unlock, the lock will go into "Sleep Mode" for one minute and for an additional minute for each subsequent incorrect entry. The keypad is disabled while in "Sleep Mode".

Error Condition Indicator

10 rapid beeps:

The lock is binding which means that either door alignment or items in the locker are preventing the lock from operating. Press on the door while operating the lock. If error condition persists, contact Digilock support for assistance.

2 sets of three beeps:

The batteries are low. Replace the batteries.

1 beep:

The lock does not recognize the User Code, User Key, Programming Key, or Manager Key.

Does not Unlock with the User Code or User Key

The lock does not recognize the User Code or User Key. For immediate access, operate with a registered Manager Key. If in assigned use functionality, follow Assign User Credential instructions to assign a new User Code or User Key to the lock.

Does not operate with a Manager Key

The lock does not recognize the Manager Key. Follow Register/Add Manager Key(s) instructions to register the Manager Key to the lock. For immediate access, operate with another registered Manager Key or with the Programming Key.

Does not operate with the Programming Key


The lock does not recognize the Programming Key. Contact Digilock support.

No Audible Feedback when 🖸 is Pressed


- The lock may be in "Sleep Mode". For immediate access, operate with a registered Manager Key.
- The batteries may need to be replaced. Operate with the Manager Key to unlock then replace the batteries.
- The front unit may not be properly connected to the rear unit. Remove the lock from the door and check the cable connection.
- If error condition persists, contact Digilock support.

Battery Replacement


It is not necessary to uninstall the lock from the door.



Remove the screws and the cover plate.



Pull the battery pack from the rear housing. Replace with four premium alkaline AA batteries.



Place the battery pack back into the rear housing and screw cover plate in place.